

Per sostituire la punta centrale ① di un trascinatore frontale a punta molleggiata, non sono necessari attrezzi o chiavi. Prendere con le mani la punta centrale e farla scorrere assialmente fino ad estrarla dalla sua sede. In caso di necessità, aiutarsi con uno straccio o un paio di pinze per una maggiore presa. Per introdurre nuovamente la punta centrale, farla scorrere in direzione dell'asse del trascinatore, fino a farla arrivare nel suo appoggio. L'operazione può essere effettuata con il trascinatore già montato in macchina, senza pregiudicare la precisione dello stesso.

To replace the center point ① of a spring-loaded face driver, no tools or keys are required. Take the center point with your hands and make it slide axially until it is extracted from its seat. If necessary, help yourself with a rag or of pliers for added grip. To introduce again the central tip, slide it towards the axis of the driver, until it reaches its support. The operation can be carried out with the driver already mounted on the machine, without compromising its accuracy

